

Solve™

INSTALLER CHECKLIST

Everything you need for a Solve Mount installation

ESSENTIAL TOOLS



**28mm Diamond
Coring Bit**



**7mm Wood Auger
Drill Bit**
Bosch PRO



Solve Drill Guide
1 per box included



7mm Hex Socket
For drill driver



**Battery Drill
Driver**
High speed, NO hammer



Tape Measure



**Rafter Finder
by Solve**
Or alternative



Chalk Marker
Or similar



**2 x 15mm
Spanners**



**1 x 17mm
Spanner**



Builders Square

PROHIBITED TOOLS

- Non-diamond coring bit
- Blunt coring bit
- Over / under sized coring bit
- Hammer action drill — never use hammer action on tile or timber
- Impact driver

CONSUMABLES



Metal Free Anti-Seize Grease
e.g. Molykote 1000 or Loctite LB 8009

Before You Start

Ensure your battery drill driver is set to HIGH SPEED mode with NO hammer action. Check your coring bit is undamaged before each install. Always use the Solve Drill Guide for accurate positioning, the helps the seal enter the hole without getting caught, ensuring even expansion.